



# **P**ush Button Switch



**TOPTEK®**  
HARDWARE ELECTRONIC MANUFACTURER  
www.toptek-co.com

## T-TOP-450/451

## T-TOP-11A/11B





T-TOP-450 ON-OFF  
T-TOP-451 OFF-(ON)  
1A 250VAC

T-TOP-11A ON-OFF  
T-TOP-11B OFF-(ON)  
1A 250VAC

## T-TOP-460/461

## T-TOP-12A/12B





T-TOP-460 ON-OFF  
T-TOP-461 OFF-(ON)  
1A 250VAC

T-TOP-12A ON-OFF  
T-TOP-12B OFF-(ON)  
1A 250VAC

## T-TOP-33B

## T-TOP-14A/14B





T-TOP-33B OFF-(ON) IP54  
1A 250VAC  
WPC-33 Waterproof cover

T-TOP-14A ON-OFF  
T-TOP-14B OFF-(ON)  
1A 250VAC

## T-TOP-227/228

## T-TOP-27B



T-TOP-227 OFF-(ON)  
T-TOP-228 ON-OFF  
1A 250VAC

T-TOP-27B OFF-(ON)  
1A 250VAC

14  
\*  
67

